


# i1 (Sota, Panini, WS)



To access INFO MODE, press the "i" key when the oven is either off or cooling down. To toggle between Info screen 1 and 2, press the Up or Down key.




## View From Info Screen 1

- Last temperature selected
- Serial number
- Menu version
- Firmware version
- Cook counter/Time logs
- Incoming voltage (US/Canada only)
- Fault logs
- Service numbers

## From Info Screen 1

	Press
Cook Counts	R1
Total Cook Time	R1
Total Magnetron Time	R1
Total "Oven On" Time	R1
Fault Log	R3
Service Phone Numbers	R4



## From Info Screen 2

	Press	Keycode
Access TEST MODE	L1	9-4-2-8 and ENTER
Access "Options" Screen	L2	9-4-2-8 and ENTER
Access "Options" Screen 2	L2	9-4-2-8 and ENTER, DOWN arrow
Change Display Language*	L3	
Set Date and Time	L4	
Access "Load Menu" Screen	R1	
Increase/Decrease Sound Volume	R2	
F2 Bypass*	R3	
View Electrical Compartment Temperature	R4	

## Feature On/Off

	Press from Options Screen 1
Adjust Time	L1
Cook More	L2
Edit Mode	L3
Load Menu	L4
Network Setup	R1
Auto Off	R2
Auto On	R3
Demo Mode	R4

## Feature On/Off

	Press from Options Screen 2
Light Ring	L1
Catalytic Recondition*	L4

\* Not available on all models.